MATLIFT BY EWP SPARES

MDL COMPACT + MDL TALL

ILLUSTRATED PARTS MANUAL

MACHINE PHOTOS / PART-NUMBER REGISTER



COMPACT

MDL3.3 / MDL4.4 / MDL5.5



TALL

MDL3 / MDL4.5 / MDL6 / MDL7.5

EDITION 03 / SEPTEMBER 2026

MATLIFT BY EWP SPARES

START HERE / IDENTIFICATION

How to order the right part

Use the machine ID plate first. Record the exact MDL model and serial number. Find the assembly area on the photo page, identify the component in the following register, then select its compact or tall family code.

PART-NUMBER FORMAT

ML-C-3508

C means compact; **T** means tall. **3508** is the cable guard. Complete cables use a model code because the assembly length follows the mast height.

FAMILY FITMENT

ML-C	MDL3.3	MDL4.4	MDL5.5	
ML-T	MDL3	MDL4.5	MDL6	MDL7.5

READING THIS MANUAL

PHOTOS	The machine and enlarged detail views locate each assembly; hidden components are listed in the register.
TABLE	REF identifies a register item, not a photo callout. Select the compact or tall family code.
MAST	Column and associated hardware quantities vary by model. Complete cable length is model-specific.

Photographs show the compact and tall MATLIFT machines. Use the exact model, serial number and the part fitted to the machine when identifying internal service items.

CONTENT MAP

Find the assembly

Each group begins with compact and tall machine photo locators. The following page lists component codes for both families.

01	**STANDARD BASE** Frame, hold-down and swivel caster	04-05
02	**FOLDING LEGS & STABILISERS** Leg pivots, stabilisers, latches and wheels	06-07
03	**MAST & WINCH MOUNT** Stiffeners, rollers, winch mount and upper cable guard	08-09
04	**CARRIAGE & CABLE ANCHOR** Anchor bracket, rollers and carriage interface	10-11
05	**MAST COLUMNS & STOPS** Stages, guide hardware, stops and couplers	12-13
06	**CABLE & PULLEYS** Pulley assemblies, cable and mast column interfaces	14-15
07	**SINGLE-SPEED WINCH** Winch internals - select only if this winch is fitted	16-17
08	**FORKS & CARRIERS** Standard and alternate fork arrangements	18-19
09	**OPTIONAL LOAD TOOLS** Pipe cradle, platform and boom arm	20-21
10	**REAR TRANSPORT WHEELS** Accessory wheels, axle, retainers and mounts	22-23

PARTS REQUEST WORKSHEET / PAGE 24

GROUP 21 / MACHINE PHOTO LOCATOR

STANDARD BASE

Frame, hold-down and swivel caster. Use the parts register on the next page for item descriptions and codes.

COMPACT

MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL

MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Central base, caster plates and hold-down area. Check the exact mounting arrangement on the unit.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 21 / SHARED FAMILY CODES

STANDARD BASE

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Mast / column interface	ML-C-2101	ML-T-2101
02	Central base assembly	ML-C-2102	ML-T-2102
03	Spacer / shim	ML-C-2103	ML-T-2103
04	Hold-down return spring	ML-C-2104	ML-T-2104
05	Mounting bolt / screw	ML-C-2105	ML-T-2105
06	Locknut / nut	ML-C-2106	ML-T-2106
07	Swivel caster assembly	ML-C-2107	ML-T-2107
08	Skid pad	ML-C-2108	ML-T-2108
09	Mounting bolt / screw	ML-C-2109	ML-T-2109
10	Washer / shim	ML-C-2110	ML-T-2110
11	Cotter pin	ML-C-2111	ML-T-2111
12	Transport hold-down kit	ML-C-2112	ML-T-2112
13	Column slide button	ML-C-2113	ML-T-2113
14	Toggle locking pin	ML-C-2114	ML-T-2114
15	Carriage / mast interface	ML-C-2115	ML-T-2115

Ordering check: use the compact or tall code above and give the exact MDL model and serial number. Column-related item quantities follow the number of stages fitted to that machine.

GROUP 23 / MACHINE PHOTO LOCATOR

FOLDING LEGS & STABILISERS

Leg pivots, stabilisers, latches and wheels. Use the parts register on the next page for item descriptions and codes.

COMPACT MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Folding legs, stabiliser struts, wheels and pivot area. Check the locks fitted to the unit.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 23 / SHARED FAMILY CODES

FOLDING LEGS & STABILISERS

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Left stabiliser support strut	ML-C-2301	ML-T-2301
02	Stabiliser pivot locknut	ML-C-2302	ML-T-2302
03	Washer / shim	ML-C-2303	ML-T-2303
04	Mounting bolt / screw	ML-C-2304	ML-T-2304
05	Stabiliser mounting bracket	ML-C-2305	ML-T-2305
06	Central base assembly	ML-C-2102	ML-T-2102
07	Folding leg pivot tube	ML-C-2307	ML-T-2307
08	Mounting bolt / screw	ML-C-2308	ML-T-2308
09	Folding leg weldment	ML-C-2309	ML-T-2309
10	Swivel caster assembly	ML-C-2310	ML-T-2310
11	Folding leg axle tube	ML-C-2311	ML-T-2311
12	Wheel assembly	ML-C-2312	ML-T-2312
13	Retaining clip / ring	ML-C-2313	ML-T-2313
14	Washer / shim	ML-C-2314	ML-T-2314
15	Mounting bolt / screw	ML-C-2315	ML-T-2315
16	Locknut / nut	ML-C-2316	ML-T-2316
17	Retaining pin / tether	ML-C-2317	ML-T-2317
18	Swivel caster assembly	ML-C-2318	ML-T-2318
19	Locknut / nut	ML-C-2319	ML-T-2319
20	Washer / shim	ML-C-2320	ML-T-2320
21	Washer / shim	ML-C-2321	ML-T-2321
22	Stabiliser leg weldment	ML-C-2322	ML-T-2322
23	Mounting bolt / screw	ML-C-2323	ML-T-2323
24	Mounting bolt / screw	ML-C-2324	ML-T-2324
25	Stabiliser latch spring	ML-C-2325	ML-T-2325
26	Stabiliser strut assembly	ML-C-2326	ML-T-2326
27	Roll pin	ML-C-2327	ML-T-2327
28	Stabiliser latch plate	ML-C-2328	ML-T-2328
29	Stabiliser clamp tube	ML-C-2329	ML-T-2329
30	Stabiliser pivot tube	ML-C-2330	ML-T-2330

GROUP 36 / MACHINE PHOTO LOCATOR

MAST & WINCH MOUNT

Stiffeners, rollers, winch mount and upper cable guard. Use the parts register on the next page for item descriptions and codes.

COMPACT

MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL

MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Winch mounting area, cable guard and loading wheels. Verify the installed guard and winch.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 36 / SHARED FAMILY CODES

MAST & WINCH MOUNT

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Winch mount locknut	ML-C-3601	ML-T-3601
02	Winch mount flat washer	ML-C-3602	ML-T-3602
03	Winch mount bolt	ML-C-3603	ML-T-3603
04	Mounting bolt / screw	ML-C-3604	ML-T-3604
05	Right mast stiffener	ML-C-3605	ML-T-3605
06	Guide roller	ML-C-3606	ML-T-3606
07	Mast stiffener spacer	ML-C-3607	ML-T-3607
08	Locknut / nut	ML-C-3608	ML-T-3608
09	Mounting bolt / screw	ML-C-3609	ML-T-3609
10	Left mast stiffener	ML-C-3610	ML-T-3610
11	Washer / shim	ML-C-3611	ML-T-3611
12	Mounting bolt / screw	ML-C-3612	ML-T-3612
13	Roller guard	ML-C-3613	ML-T-3613
14	Winch mounting plate	ML-C-3614	ML-T-3614
15	Mounting bolt / screw	ML-C-3615	ML-T-3615
16	Locknut / nut	ML-C-3616	ML-T-3616
17	Manual holder / tube	ML-C-3617	ML-T-3617
18	Clamp / tube mount	ML-C-3618	ML-T-3618
19	Retaining rivet	ML-C-3619	ML-T-3619
20	Mounting bolt / screw	ML-C-3620	ML-T-3620
21	Washer / shim	ML-C-3621	ML-T-3621
22	Retaining pin / tether	ML-C-3622	ML-T-3622
23	Handle grip	ML-C-3623	ML-T-3623
24	Washer / shim	ML-C-3624	ML-T-3624
25	Washer / shim	ML-C-3625	ML-T-3625
26	Wheel assembly	ML-C-3626	ML-T-3626
27	Loading wheel assembly	ML-C-3627	ML-T-3627
28	Winch spacer	ML-C-3628	ML-T-3628
29	Winch assembly	ML-C-3629	ML-T-3629
30	Upper cable guard kit	ML-C-3508	ML-T-3508

GROUP 37 / MACHINE PHOTO LOCATOR

CARRIAGE & CABLE ANCHOR

Anchor bracket, rollers and carriage interface. Use the parts register on the next page for item descriptions and codes.

COMPACT

MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL

MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA




PHOTO LOCATOR

Moving carriage and mast interface. Anchor and roller internals are identified from the removed part.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 37 / SHARED FAMILY CODES

CARRIAGE & CABLE ANCHOR

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Mounting bolt / screw	ML-C-3701	ML-T-3701
02	Washer / shim	ML-C-3702	ML-T-3702
03	Locknut / nut	ML-C-3703	ML-T-3703
04	Cable anchor bracket kit	ML-C-3704	ML-T-3704
05	Washer / shim	ML-C-3705	ML-T-3705
06	Locknut / nut	ML-C-3706	ML-T-3706
07	Wire-rope assembly	SEE CABLE CODES	SEE CABLE CODES
08	Mounting bolt / screw	ML-C-3708	ML-T-3708
09	Washer / shim	ML-C-3709	ML-T-3709
10	Guide roller	ML-C-3606	ML-T-3606
11	Roller guard	ML-C-3613	ML-T-3613
12	Carriage assembly	ML-C-3712	ML-T-3712
13	Mast reinforcement plate	ML-C-3713	ML-T-3713
14	Washer / shim	ML-C-3714	ML-T-3714
15	Fixed mast column	ML-C-3803	ML-T-3803

COMPLETE CABLE ASSEMBLY - LENGTH BY MODEL

COMPACT	MATLIFT CODE	TALL	MATLIFT CODE
MDL3.3	ML-33-3914	MDL3	ML-30-3914
MDL4.4	ML-44-3914	MDL4.5	ML-45-3914
MDL5.5	ML-55-3914	MDL6	ML-60-3914
		MDL7.5	ML-75-3914

GROUP 38 / MACHINE PHOTO LOCATOR

MAST COLUMNS & STOPS

Stages, guide hardware, stops and couplers. Use the parts register on the next page for item descriptions and codes.

COMPACT MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Nested mast columns and end stops. Count the column stages fitted to the exact machine.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 38 / SHARED FAMILY CODES

MAST COLUMNS & STOPS

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Locknut / nut	ML-C-3801	ML-T-3801
02	Washer / shim	ML-C-3802	ML-T-3802
03	Fixed / first mast column	ML-C-3803	ML-T-3803
04	Roller guard	ML-C-3613	ML-T-3613
05	Guide roller	ML-C-3606	ML-T-3606
06	Mounting bolt / screw	ML-C-3806	ML-T-3806
07	Second mast column	ML-C-3807	ML-T-3807
08	Column mounting screw	ML-C-3808	ML-T-3808
09	Locknut / nut	ML-C-3809	ML-T-3809
10	Upper mast stop	ML-C-3810	ML-T-3810
11	Lower mast stop	ML-C-3811	ML-T-3811
12	Locknut / nut	ML-C-3812	ML-T-3812
13	Spacer / shim	ML-C-3813	ML-T-3813
14	Mounting bolt / screw	ML-C-3814	ML-T-3814
15	Washer / shim	ML-C-3815	ML-T-3815
16	Locknut / nut	ML-C-3816	ML-T-3816
17	Washer / shim	ML-C-3817	ML-T-3817
18	Mounting bolt / screw	ML-C-3818	ML-T-3818
19	Lower mast stop - alternate position	ML-C-3819	ML-T-3819
20	Washer / shim	ML-C-3820	ML-T-3820
21	Column coupler bar	ML-C-3821	ML-T-3821
22	End block - down stop	ML-C-3822	ML-T-3822
23	Down-stop rubber bumper	ML-C-3823	ML-T-3823
24	Mounting bolt / screw	ML-C-3824	ML-T-3824
25	Down-stop tube	ML-C-3825	ML-T-3825
26	Down-stop plunger	ML-C-3826	ML-T-3826
27	Down-stop doubler plate	ML-C-3827	ML-T-3827

Ordering check: use the compact or tall code above and give the exact MDL model and serial number. Column-related item quantities follow the number of stages fitted to that machine.

GROUP 39 / MACHINE PHOTO LOCATOR

CABLE & PULLEYS

Pulley assemblies, cable and mast column interfaces. Use the parts register on the next page for item descriptions and codes.

COMPACT MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Cable route and upper pulley area. Some pulley and cable hardware sits behind guards.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 39 / SHARED FAMILY CODES

CABLE & PULLEYS

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Pulley fixing screw	ML-C-3901	ML-T-3901
02	Washer / shim	ML-C-3902	ML-T-3902
03	Pulley / sheave	ML-C-3903	ML-T-3903
04	Pulley cover	ML-C-3904	ML-T-3904
05	Inner pulley mount	ML-C-3905	ML-T-3905
06	Mounting bolt / screw	ML-C-3906	ML-T-3906
07	Washer / shim	ML-C-3907	ML-T-3907
08	Mounting bolt / screw	ML-C-3908	ML-T-3908
09	Washer / shim	ML-C-3909	ML-T-3909
10	Locknut / nut	ML-C-3910	ML-T-3910
11	First pulley mount	ML-C-3911	ML-T-3911
12	Mounting bolt / screw	ML-C-3912	ML-T-3912
13	Locknut / nut	ML-C-3913	ML-T-3913
14	Wire-rope assembly	SEE CABLE CODES	SEE CABLE CODES
15	Fixed mast column	ML-C-3803	ML-T-3803
16	Moving mast column	ML-C-3807	ML-T-3807
17	Carriage assembly	ML-C-3712	ML-T-3712

COMPLETE CABLE ASSEMBLY - LENGTH BY MODEL

COMPACT	MATLIFT CODE	TALL	MATLIFT CODE
MDL3.3	ML-33-3914	MDL3	ML-30-3914
MDL4.4	ML-44-3914	MDL4.5	ML-45-3914
MDL5.5	ML-55-3914	MDL6	ML-60-3914
		MDL7.5	ML-75-3914

GROUP 46 / MACHINE PHOTO LOCATOR

SINGLE-SPEED WINCH

Winch internals - select only if this winch is fitted. Use the parts register on the next page for item descriptions and codes.

COMPACT

MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL

MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA




PHOTO LOCATOR

Externally visible winch area. Identify brake, ratchet and gear internals during service.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 46 / SHARED FAMILY CODES

SINGLE-SPEED WINCH

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Brake friction disc	ML-C-4601	ML-T-4601
02	Pinion gear and disc	ML-C-4602	ML-T-4602
03	Pinion shaft	ML-C-4603	ML-T-4603
04	Retaining ring	ML-C-4604	ML-T-4604
05	Pinion bushing	ML-C-4605	ML-T-4605
06	Winch handle	ML-C-4606	ML-T-4606
07	Locknut / nut	ML-C-4607	ML-T-4607
08	Ratchet pawl kit	ML-C-4608	ML-T-4608
09	Cable keeper kit	ML-C-4609	ML-T-4609
10	Drum bolt spacer	ML-C-4610	ML-T-4610
11	Drum bolt lock	ML-C-4611	ML-T-4611
12	Winch gear cover	ML-C-4612	ML-T-4612
13	Mounting bolt / screw	ML-C-4613	ML-T-4613
14	Locknut / nut	ML-C-4614	ML-T-4614
15	Drum spacer bolt	ML-C-4615	ML-T-4615
16	Locknut / nut	ML-C-4616	ML-T-4616
17	Frame spacer	ML-C-4617	ML-T-4617
18	Pinion shaft spacer	ML-C-4618	ML-T-4618
19	Pinion plate	ML-C-4619	ML-T-4619
20	Ratchet gear	ML-C-4620	ML-T-4620

Ordering check: use the compact or tall code above and give the exact MDL model and serial number. Column-related item quantities follow the number of stages fitted to that machine.

GROUP 41 / MACHINE PHOTO LOCATOR

FORKS & CARRIERS

Standard and alternate fork arrangements. Use the parts register on the next page for item descriptions and codes.

COMPACT

MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL

MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA




PHOTO LOCATOR

Fork and carrier area. Alternative carriers and fork attachments may differ from the photos.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 41 / SHARED FAMILY CODES

FORKS & CARRIERS

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Adjustable fork arm	ML-C-4101	ML-T-4101
02	Fork toggle pin	ML-C-4102	ML-T-4102
03	Adjustable fork carrier	ML-C-4103	ML-T-4103
04	Short fork lock pin	ML-C-4104	ML-T-4104
05	Ball-retaining pin	ML-C-4105	ML-T-4105
06	Fork extension	ML-C-4106	ML-T-4106
07	Long fork lock pin	ML-C-4107	ML-T-4107
08	Flat-fork socket	ML-C-4108	ML-T-4108
09	Mounting bolt / screw	ML-C-4109	ML-T-4109
10	Locknut / nut	ML-C-4110	ML-T-4110
11	Flat-fork casting	ML-C-4111	ML-T-4111
12	Flat-fork carrier	ML-C-4112	ML-T-4112
13	Standard fork set	ML-C-4113	ML-T-4113
14	Fork attachment weldment	ML-C-4114	ML-T-4114

Attachment fitment: Flat forks are not for MDL4.4 or MDL5.5. A shared component code does not change model-specific attachment limits; use the matching operator manual load chart.

GROUP 43 / MACHINE PHOTO LOCATOR

OPTIONAL LOAD TOOLS

Pipe cradle, platform and boom arm. Use the parts register on the next page for item descriptions and codes.

COMPACT MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Optional load tools are not fitted in the photographs. Identify the actual tool and carrier.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 43 / SHARED FAMILY CODES

OPTIONAL LOAD TOOLS

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Pipe cradle wing nut	ML-C-4301	ML-T-4301
02	Pipe cradle U-bolt	ML-C-4302	ML-T-4302
03	Pipe cradle	ML-C-4303	ML-T-4303
04	Load platform	ML-C-4304	ML-T-4304
05	Boom clevis	ML-C-4305	ML-T-4305
06	Ball-retaining pin	ML-C-4306	ML-T-4306
07	Toggle pin	ML-C-4307	ML-T-4307
08	Boom arm assembly	ML-C-4308	ML-T-4308

Ordering check: use the compact or tall code above and give the exact MDL model and serial number. Column-related item quantities follow the number of stages fitted to that machine.

GROUP 44 / MACHINE PHOTO LOCATOR


REAR TRANSPORT WHEELS

Accessory wheels, axle, retainers and mounts. Use the parts register on the next page for item descriptions and codes.

COMPACT MDL3.3 / MDL4.4 / MDL5.5



ASSEMBLY AREA



TALL MDL3 / MDL4.5 / MDL6 / MDL7.5



ASSEMBLY AREA



PHOTO LOCATOR

Base shown for location only; optional rear transport wheel hardware is not pictured.

Photos locate the assembly area; they do not depict every component in the register.

GROUP 44 / SHARED FAMILY CODES

REAR TRANSPORT WHEELS

REF is this group's item index. One compact code covers MDL3.3 / MDL4.4 / MDL5.5; one tall code covers MDL3 / MDL4.5 / MDL6 / MDL7.5. Confirm the model and serial before ordering.

REF	COMPONENT	COMPACT / ML-C	TALL / ML-T
01	Wheel spacer weldment	ML-C-4401	ML-T-4401
02	Rear transport wheel	ML-C-4402	ML-T-4402
03	Right wheel mount	ML-C-4403	ML-T-4403
04	Axle retaining ring	ML-C-4404	ML-T-4404
05	Rear wheel axle rod	ML-C-4405	ML-T-4405
06	Shim washer	ML-C-4406	ML-T-4406
07	Left wheel mount	ML-C-4407	ML-T-4407
08	Mounting screw	ML-C-4408	ML-T-4408
09	Locknut	ML-C-4409	ML-T-4409

Ordering check: use the compact or tall code above and give the exact MDL model and serial number. Column-related item quantities follow the number of stages fitted to that machine.

ORDERING / MODEL & SERIAL

Parts request worksheet

Attach a clear photograph of the machine, its ID plate, the installed assembly and the part to be replaced.

BUSINESS / CONTACT	DATE
MACHINE MODEL	SERIAL NUMBER
COMPACT / TALL FAMILY	MAST COLUMNS FITTED
FITTED WINCH TYPE	PARTS GROUP
REGISTER ITEM (REF)	MATLIFT PART CODE
PART DESCRIPTION	QUANTITY
PHOTOS ATTACHED	CONTACT PHONE / EMAIL

Parts identification: The photographs locate external assembly areas; the parts register also includes internal components. Codes are shared within each compact or tall family. Mast column and related part quantities vary with the fitted height. Match the complete cable assembly to the exact machine model and serial number.